

**Avant, Rear**  
From June 2011




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Comfort System Central Control Module, Left Back-Up Lamp Bulb, Left Brake/Tail Lamp Bulb, Left Rear Parking/Fog Lamp Bulb

- J393 Comfort System Central Control Module
- M6 Left Rear Turn Signal Bulb
- M9 Left Brake Lamp Bulb
- M16 Left Back-Up Lamp Bulb
- M21 Left Brake/Tail Lamp Bulb
- M41 Left Rear Parking/Fog Lamp Bulb
- M58 Left Brake/Tail Lamp Bulb 2
- T3x 3-Pin Connector
- T4cz 4-Pin Connector
- T17r 17-Pin Connector
- T17s 17-Pin Connector

- 50 Ground Connection in Luggage Compartment, Left
- 51 Ground Connection in Luggage Compartment, Right
- 382 Ground Connection 17 (in Main Wiring Harness)
- 387 Ground Connection 22 (in Main Wiring Harness)






Suppressor, Comfort System Central Control Module, Right Rear Turn Signal Bulb, Right Brake Lamp Bulb, Right Back-Up Lamp Bulb, High-Mounted Brake Lamp Bulb, Right Rear Parking/Fog Lamp Bulb

- C24 Suppressor
- J393 Comfort System Central Control Module
- M8 Right Rear Turn Signal Bulb
- M10 Right Brake Lamp Bulb
- M17 Right Back-Up Lamp Bulb
- M22 Right Brake/Tail Lamp Bulb
- M25 High-Mounted Brake Lamp Bulb
- M42 Right Rear Parking/Fog Lamp Bulb
- M59 Right Brake/Tail Lamp Bulb 2
- T2da 2-Pin Connector
- T2lc 2-Pin Connector
- T3bc 3-Pin Connector
- T4cy 4-Pin Connector
- T8a 8-Pin Connector
- T17r 17-Pin Connector
- T17s 17-Pin Connector
- T32g 32-Pin Connector
- Y7 Automatic Dimming Interior Rearview Mirror
- 387 Ground Connection 22 (in Main Wiring Harness)
- B469 Connection 5 (in Main Wiring Harness)
- B479 Connection 15 (in Main Wiring Harness)
- \* Refer to Applicable Standard Equipment Wiring Diagram

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


ws = white  
 sw = black  
 ro = red  
 rt = red  
 br = brown  
 gn = green  
 bl = blue  
 gr = grey  
 li = lilac  
 vi = lilac  
 ge = yellow  
 or = orange  
 rs = pink



# Comfort System Central Control Module, Rear Lid Central Locking System Motor, Luggage Compartment Lamp


- F124 Rear Lid Lock Cylinder/Anti-Theft Alarm/Central Locking Contact Switch
- J393 Comfort System Central Control Module
- T2bz 2-Pin Connector
- T2la 2-Pin Connector
- T2lb 2-Pin Connector
- T4bz 4-Pin Connector
- T17r 17-Pin Connector
- T17s 17-Pin Connector
- T32g 32-Pin Connector
- V53 Rear Lid Central Locking System Motor
- W3 Luggage Compartment Lamp

- 51 Ground Connection in Luggage Compartment, Right
- 386 Ground Connection 21 (in Main Wiring Harness)
- 389 Ground Connection 24 (in Main Wiring Harness)
- B447 Luggage Compartment Lamp Connection (in Main Wiring Harness)




Rear Lid Lock Cylinder Unlock Button, Comfort System Central Control Module, Door Closing Aid Control Module, Left License Plate Lamp, Right License Plate Lamp

- F248 Rear Lid Lock Cylinder Unlock Button
- F332 Rear Lid Closing Aid/Unlock Stop Switch
- F333 Rear Lid Closing Aid/Lock Stop Switch
- J393 Comfort System Central Control Module
- J657 Door Closing Aid Control Module
- T2dh 2-Pin Connector
- T2di 2-Pin Connector
- T2es 2-Pin Connector
- T5ag 5-Pin Connector, In the Luggage Compartment, Right
- T17s 17-Pin Connector
- T32g 32-Pin Connector
- T32h 32-Pin Connector
- T32i 32-Pin Connector
- V382 Rear Lid Closing Aid Motor
- X4 Left License Plate Lamp
- X5 Right License Plate Lamp
- 383 Ground Connection 18 (in Main Wiring Harness)
- B132 License Plate Lamp Connection (in Interior Wiring Harness)



Windshield Antenna Suppression Filter, Right Rear Window Breakage Sensor, Rear Window Breakage Sensor, Rear Window Defogger Relay, Comfort System Central Control Module, Rear Window Defogger

- C18 Windshield Antenna Suppression Filter, Behind the Right Luggage Compartment Side Trim
- G183 Left Rear Window Breakage Sensor
- G184 Right Rear Window Breakage Sensor
- G304 Rear Window Breakage Sensor
- J9 Rear Window Defogger Relay, On the Relay and Fuse Panel in the Luggage Compartment, Right
- J393 Comfort System Central Control Module
- R178 Fm Frequency Filter in Negative Wire
- R179 Fm Frequency Filter in Positive Wire
- SF3 Fuse 3 (On Fuse Panel F)
- ST5 Fuse Panel 5
- T2ku 2-Pin Connector
- T2kv 2-Pin Connector, On the Rear Window
- T2kw 2-Pin Connector
- T32g 32-Pin Connector
- T32i 32-Pin Connector
- Z1 Rear Window Defogger
- 653 Ground Connection on Left D-Pillar
- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 From June 2014



# Power Rear Lid Opening Sensor, Power Rear Lid Opening Sensor 2, Comfort System Central Control Module, Power Rear Lid Opening Control Module

- G750 Power Rear Lid Opening Sensor, In the Rear Bumper
- G760 Power Rear Lid Opening Sensor 2, In the Rear Bumper
- J393 Comfort System Central Control Module
- J938 Power Rear Lid Opening Control Module
- ST2 Fuse Panel 2
- SF5 Fuse 5 (On Fuse Panel F)
- S41 Rear Window Defogger Fuse
- S133 Safety Fuse 3
- S195 Rear Lid Remote Unlocking Fuse, On the Relay and Fuse Panel

Protected by copyright. Copying for private or internal use is not permitted unless authorised by AUDI AG. AUDI AG does not accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- T4fh 4-Pin Connector
- T5ao 5-Pin Connector
- T8av 8-Pin Connector, Behind the Right Luggage Compartment Side Trim
- T16v 16-Pin Connector, Behind the Right Luggage Compartment Side Trim, Brown
- T32i 32-Pin Connector

- 744 Ground Connection in Spare Tire Well

- B298 Positive Connection 2 (30) (in Main Wiring Harness)

- \* Main Fuse Carrier in the Right Rear Luggage Compartment, at the Battery
- \*2 Depending on Equipment
- \*3 From June 2014
- \*4 Refer to Applicable Wiring Diagram for Fuse Positions
- \*5 Running Change

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink



\* Refer to Applicable Wiring Diagram for Fuse Positions  
\*2 From June 2014

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


# Rear Lid Lock Button in Luggage Compartment, Rear Lid Control Module, Luggage Compartment Cover Motor 1

- E406 Rear Lid Lock Button in Luggage Compartment
- J605 Rear Lid Control Module
- ST2 Fuse Panel 2
- SF9 Fuse 9 (On Fuse Panel F)
- T4bx 4-Pin Connector
- T4by 4-Pin Connector
- T6aw 6-Pin Connector
- T26b 26-Pin Connector
- T46b 46-Pin Connector, On the Relay and Fuse Panel in the Luggage Compartment, Right
- V473 Luggage Compartment Cover Motor 1


51 Ground Connection in Luggage Compartment, Right

385 Ground Connection 20 (in Main Wiring Harness)

- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 Data Bus Wire (CAN Bus)
- \*3 Refer to Applicable Wiring Diagram for Data Bus Networking



Rear Lid -Closed- Sensor 1, Rear Lid Warning Buzzer, Rear Lid Control Module, Rear Lid Motor 1, Rear Lid Motor 2



- G525 Rear Lid -Closed- Sensor 1
- G526 Rear Lid -Closed- Sensor 2
- H32 Rear Lid Warning Buzzer
- J605 Rear Lid Control Module
- N527 Coupling in Rear Lid Motor 1
- N528 Coupling in Rear Lid Motor 2
- T2is 2-Pin Connector
- T5ae 5-Pin Connector
- T5ah 5-Pin Connector
- T5r 5-Pin Connector
- T12an 12-Pin Connector
- T12l 12-Pin Connector
- T26b 26-Pin Connector
- V444 Rear Lid Motor 1
- V445 Rear Lid Motor 2

395 Ground Connection 30 (in Main Wiring Harness)

\* Running Change

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

ws = white  
sw = black  
ro = red  
rt = red  
br = brown  
gn = green  
bl = blue  
gr = grey  
li = lilac  
vi = lilac  
ge = yellow  
or = orange  
rs = pink




J533	Data Bus on Board Diagnostic Interface
R78	TV Tuner
ST3	Fuse Panel 3
SF11	Fuse 11 (On Fuse Panel F)
T2by	2-Pin Connector
T20d	20-Pin Connector
T32b	32-Pin Connector

- |      |  |
|------|--|
| 50   | Ground Connection in Luggage Compartment, Left |
| 381  | Ground Connection 16 (in Main Wiring Harness)  |
| B444 | OBD Connection 1 (in Main Wiring Harness)      |

- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 For Vehicles with Bose Sound System
- \*3 For Vehicles with Bang & Olufsen Sound System
- \*4 Fiber Optic Cable
- \*5 Refer to Applicable Wiring Diagram for Data Bus Networking
- \*6 For Vehicles with Audi Sound System

TV Tuner, Antenna Amplifier 3, Antenna Amplifier 4



- J794 Information Electronics Control Module 1
- R Radio
- R56 TV Antenna 2
- R57 TV Antenna 3
- R78 TV Tuner
- R112 Antenna Amplifier 3, In the Left Side Window
- R113 Antenna Amplifier 4, Rear Window, Upper Right
- R183 Digital Radio Antenna
- T2br 2-Pin Connector
- T2bs 2-Pin Connector
- T2bt 2-Pin Connector
- T2bu 2-Pin Connector
- T2bv 2-Pin Connector
- T4an 4-Pin Connector
- T4ar 4-Pin Connector
- T4as 4-Pin Connector
- \* For Vehicles with Digital Radio
- \*2 For Vehicles Without TV Reception
- \*3 For Vehicles with Japan Equipment


- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# Antenna Amplifier, TV Tuner

- J794 Information Electronics Control Module 1
- R Radio
- R11 Antenna
- R24 Antenna Amplifier, Rear Window, Lower Left
- R55 TV Antenna 1
- R78 TV Tuner
- T2bw 2-Pin Connector
- T4ao 4-Pin Connector
- T4ap 4-Pin Connector
- T4ar 4-Pin Connector
- \* For Vehicles with Japan Equipment
- \*2 For Vehicles Without TV Reception


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

# TV Tuner, TV Card Reader

- J794 Information Electronics Control Module 1
- R78 TV Tuner
- R161 DVD Changer
- R204 TV Card Reader
- T2as 2-Pin Connector
- T2bi 2-Pin Connector, Relay Panel Under the Instrument Panel, Left
- T2bp 2-Pin Connector
- T2bx 2-Pin Connector
- T4di 4-Pin Connector
- T4dk 4-Pin Connector
- \* For Vehicles with Japan Equipment
- \*2 For Vehicles with DVD Player



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink